



**Durable  
GreenBed™**  
FOR THE SERIOUS GARDENER

## INSTALLATION INSTRUCTIONS FOR SQUARE AND RECTANGULAR 2' TALL KITS

Congratulations on purchasing the finest raised bed garden kit on the market. Your completed GreenBed™ will provide many years of service, far in excess of wood.

### PARTS LIST:

**4'x4' BED:** (4) GreenBed™ panels 45 3/4" x 25", (4) alum. corners, (4) alum. corner trim caps (4) cedar trim pieces

**4'x8' BED:** (6) GreenBed™ panels 45 3/4" x 25", (4) alum. corners, (4) alum. corner trim caps, (2) alum. joiners and (2) alum. joiner trim caps, (2) alum. tension straps, (6) cedar trim pieces

**4'x12' BED:** (8) GreenBed™ panels 45 3/4" x 25", (4) alum. corners, (4) alum. corner trim caps, (4) alum. joiners and (4) alum. joiner trim caps, (4) alum. tension straps, (8) cedar trim pieces

**4'x16' BED:** (10) GreenBed™ panels 45 3/4" x 25", (4) alum. corners, (4) alum. corner trim caps, (6) alum. joiners and (6) alum. joiner trim caps, (6) alum. tension straps, (10) cedar trim pieces


**4'x20' BED:** (12) GreenBed™ panels 45 3/4" x 25", (4) alum. corners, (4) alum. corner trim caps, (8) alum. joiners and (8) alum. joiner trim caps, (8) alum. tension straps, (12) cedar trim pieces

**4'x24' BED:** (14) GreenBed™ panels 45 3/4" x 25", (4) alum. corners, (4) alum. corner trim caps, (10) alum. joiners and (10) alum. joiner trim caps, (10) alum. tension straps, (14) cedar trim pieces

**ALL KITS:** (1) Package of 1 1/2" metal bracket screws, 3" gray cap screws and 3" color-matched trim screws

### TOOLS NEEDED:

Rake, shovel, a bench or set of saw horses, tape measure, level (or laser level), rubber mallet, 1/8" drill bit, cordless drill with a 1/4" nut driver and a Phillips bit.




(\* joiner caps and brackets, and tension straps not included in 4' x 4' kit)

**CAUTION:** Be careful handling the GreenBed™ panels. DO NOT WALK ON THEM. They are strong, but CAN FRACTURE if handled roughly during installation. Also, DO NOT over tighten screws. Doing so may cause them to strip out.



**1** **Level the garden site. This step is VERY IMPORTANT. If the site is level, installation will be MUCH FASTER.** Remove rocks, roots and debris that may prevent the panels from sitting straight and level. Using a laser level to check your work can speed up this process. Compact the soil where the walls of the bed will rest.

**2** Place a Durable GreenBed™ panel on your saw horses or work table, **smooth side up**. Line up a corner bracket so it is 1/16" - 1/8" below the top of the panel. This way, the bracket won't interfere with the trim installation



**Corner brackets**



later. Use **1-1/2"** screws to attach the bracket. Make sure each screw goes in straight. Use a cordless drill with a low torque setting, so that you don't spin out the screws. Now, install a corner bracket on the opposite side of this panel using the same steps. After you've attached the first two corner brackets, set this finished panel aside and repeat these steps on a new panel. You should now have two completed end panels, each with corner brackets.

**3** **NOTE: This step doesn't apply to 4' x 4' GreenBeds. Please skip to Step 4.**



**NOTE: One GreenBed™ panel has a joiner bracket on the left, and the other, a bracket on the right.**

Next, outfit two new panels, each with one joiner bracket. Place a new Durable GreenBed™ panel on your work table, smooth side up. Line up a flat, joiner bracket with the top of the panel. **NOTE: Make sure the bracket sits 1/16" - 1/8"** below the top of the panel. Attach the bracket with **1-1/2"** screws and set this panel aside. Next, create a second side panel, however this one will have the joiner bracket on the opposite side. See the picture above. These instructions describe how to install a 4' x 8' x 2' bed. Longer Durable GreenBeds will repeat these steps until all joiner brackets have been used.

**4** Now you are ready to start assembling the panels in your garden! Move one of the end panels with corner brackets to the garden, and a side panel containing a joiner bracket. **NOTE: If you are building a 4' x 4' Durable GreenBed™, you will be using a panel without joiner brackets to attach to your end panel with corner brackets. All panels should be facing up, which is the side that has the bracket approximately 1/16" - 1/8"** below the top of your panel.



**Each time you join two panels together with a bracket, follow these steps:**

- 1) Make sure each panel is level
- 2) Make sure they meet flush from top to bottom against the bracket
- 3) Make sure the tops of each panel meet at the same height.
- 4) Make sure that screws are straight when you drive them into a panel

**Dig out dirt from under a panel to lower it, or raise a panel by placing a folded piece of your cardboard packaging under a panel. (Your shovel is a good tool to act as a lever.)**



Once both panels are level and meet at the same height, join them with **1-1/2"** screws. Now, install the second side panel, with the attached joiner bracket, into the empty corner of the end panel. Again, make sure the panel and bracket fit flush from top to bottom, their heights match, and the panels are level before joining them with the **1-1/2"** screws. Longer beds will continue with these steps until you use all of your side panels.

**NOTE: If you are setting up a 4' x 4' Durable GreenBed™, skip to Step 7.**




Now, install the included metal straps between each joiner bracket. Gently bend the straps, as needed, to insert them into the slots. This will keep the sides of your raised bed from spreading during installation and later when you fill it with soil.



**6** Next, attach another side panel to extend the length of your GreenBed™. Dig out soil underneath the panel, or use a cardboard shim to keep the top of all panels level. Make sure the new panel is level and meets the previous side panel evenly at the joiner bracket. Then, attach the panel to the previous joiner bracket with 1 1/2" screws. **NOTE: You can see if panels are meeting at the right height by sighting down their length. This will also help you see if you have any sloping panels.** Once this new panel is installed, add tension straps between the joiner brackets to hold them together. For longer beds, keep adding side panels and tension straps until you reach Step 7.



**NOTE: Sight down the walls of your GreenBed™ to make sure that the sidewalls form a straight line.** Move the side panels or the end panel until they look straight.




Now, install the final end panel with the pre-installed corners to complete the bed. Check that the end panel is level, and adjust the side walls so they meet evenly with the corners of the end panel. Use 1-1/2" screws to secure the corner brackets to the side panels.



**Check your finished bed for squareness by measuring both directions diagonally.** Dimensions should be within 3/8" of each other. Adjust panels as necessary to square it up.



9



**NOTE:** 4' x 4' Durable GreenBed™ kits do not include the joiner brackets and joiner caps seen above.

Finally, place your trim pieces so that each one covers a panel around your Durable GreenBed™. Drop the corner and joiner caps over your trim and into the appropriate bracket holes. These will hold your trim securely. Slide each piece of trim back and forth before you add screws so that it sits more evenly between the caps. **IMPORTANT: Drill 1/8" pilot holes into the trim at each trim cap screw hole. Drill through the trim, without going into the panel.** Use **3" gray screws** to secure the cap, trim, and panel together.



Finish securing each trim piece with two additional **color-matched, 3" screws** in the predrilled holes.

Finally, fill your Durable GreenBed™ with a compost-rich, top soil blend for best results. Do not fill with heavy clay soil as it puts much higher pressure on the side walls and it's not a good choice horticulturally.

Congratulations, your Durable GreenBed™ installation is complete.